



## CUSTOMER INSTRUCTIONS AND INFORMATION

VERY IMPORTANT, MUST READ, AS THIS COULD AFFECT YOUR WARRANTY

### OPERATING INSTRUCTIONS:

- TO OPERATE YOUR **COOLABAH** THERE ARE 2 MODES:
  1. AUTOMATIC
    - This mode will adjust the temperature and will allow the unit to heat or cool as required with one simple process.
    - Turn the unit on using the on/off button, set the required temperature you would like the cabin to be via the up and down buttons, ensure the auto light is on, if not on, press the auto button once and this should put the unit into automatic mode.
  2. MANUAL
    - Turn the unit on by pressing the on/off button, select the mode you require via the mode switch, this is displayed as a snowflake for cooling only or a heater coil wire for heating only or no indicator light for fan only. Once you have the designated mode, adjust the temperature you require using the up and down switch.

### IMPORTANT INFORMATION:

- The **COOLABAH** condenser/compressor assembly that is located under the cab of the truck or on the rear of the cab must be regularly cleaned out (every 3 months) from any dirt or debris by hosing the condenser fins through the mesh on both sides of the unit until clear water runs from the unit.  
DO NOT USE PRESSURE WASHER ON YOUR COOLABAH AS THIS WILL DAMAGE THE UNIT.
- Inside the truck cabin, the **COOLABAH** evaporator has a lint/pollen filter. This filter must be removed and cleaned by blowing compressed air every 3 months or more frequently depending on the conditions the truck operates in.
- **Most importantly: DO NOT** leave your lithium battery or AGM batteries sitting idle for a period of more than 3 months. As this will cause unrepairable damage to your battery and will not be covered under warranty. This can be simply done by making sure that the vehicle is started and run for a minimum of 30 minutes every couple of weeks.

For any further information or any technical help with your **COOLABAH**, please do not hesitate to call

David at 0414 274 444



## Coolabah DCAC Maintenance Schedule

Frequency	Item to check	Maintenance
On truck service schedule	Check unit operation, Unit turns on and gets cold.	If unit does not turn on or does not get cold, contact Coolabah service agent
Once a month	Condenser/compressor unit	Clean condenser unit with garden hose (not pressure washer). If operating in dusty conditions carry out more regular cleaning and blow with air gun before washing.
6 to 12 months	Air intake/pollen filter	Clean and or replace pollen filter
2years	Coolabah service	Contact Coolabah agent to organised coolabah service and check.

For bookings or information please call MVM Autos on 02 9833 1900